### **NAME**

netfpga10g\_nf10bmac - driver for the NetFPGA-10G Embedded CPU Ethernet Core

### **SYNOPSIS**

device netfpga10g\_nf10bmac

# **DESCRIPTION**

The **netfpga10g\_nf10bmac** device driver provides support for the NetFPGA-10G Embedded CPU Ethernet Core.

## **HARDWARE**

The current version of the **netfpga10g\_nf10bmac** driver works with one PIO mode interface of the NetFPGA-10G Embedded CPU Ethernet Core version 1.00a.

### **SEE ALSO**

netintro(4), ifconfig(8)

NetFPGA-10G Wiki, https://github.com/NetFPGA/NetFPGA-public/wiki.

## **HISTORY**

The netfpga10g\_nf10bmac device driver first appeared in FreeBSD 11.0.

## **AUTHORS**

This software and this manual page were developed by SRI International and the University of Cambridge Computer Laboratory under DARPA/AFRL contract (FA8750-11-C-0249) ("MRC2"), as part of the DARPA MRC research programme. The device driver was written by Bjoern A. Zeeb.