

NAME

amdsmn - device driver for AMD processor System Management Network

SYNOPSIS

To compile this driver into the kernel, place the following line in your kernel configuration file:

```
device amdsmn
```

Alternatively, to load the driver as a module at boot time, place the following line in loader.conf(5):

```
amdsmn_load="YES"
```

DESCRIPTION

The **amdsmn** driver provides support for resources on the System Management Network bus in AMD Family 17h processors.

SEE ALSO

loader(8)

HISTORY

The **amdsmn** driver first appeared in FreeBSD 12.0.

AUTHORS

Conrad Meyer <*cem@FreeBSD.org*>