

**NAME**

**aw\_mmc** - driver for the SD/MMC controller in Allwinner SoC

**SYNOPSIS**

**device mmc**

**DESCRIPTION**

The **aw\_mmc** device driver provides support for the Allwinner SD/MMC host controller.

**HARDWARE**

The current version of the **aw\_mmc** driver supports the SD/MMC controller with one of the following compatible strings :

- ⊕ allwinner,sun4i-a10-mmc
- ⊕ allwinner,sun5i-a13-mmc
- ⊕ allwinner,sun7i-a20-mmc
- ⊕ allwinner,sun50i-a64-mmc

**SYSCTL VARIABLES**

The following read-only variables are available via `sysctl(8)`:

*dev.aw\_mmc.req\_timeout*

Request timeout in seconds (default: 10) .

**SEE ALSO**

`fdt(4)`, `mmc(4)`

**HISTORY**

The **aw\_mmc** device driver first appeared in FreeBSD 10.0.

**AUTHORS**

The **aw\_mmc** device driver was originally written by Alexander Fedorov <[alexander.fedorov@rtlservice.com](mailto:alexander.fedorov@rtlservice.com)>. Later work and this manual page was done by Emmanuel Vadot <[manu@freebsd.org](mailto:manu@freebsd.org)>.