

**NAME**

**efitable** - Dump UEFI tables

**SYNOPSIS**

**efitable** [-u *uuid* | -t *name*] [--libxo]

**DESCRIPTION**

This program prints data from "Unified Extensible Firmware Interface" (UEFI) tables.

The following options are available:

- libxo** Generate output via libxo(3) in a selection of different human and machine readable formats. See `xo_parse_args(3)` for details on command line arguments.
- t *name* --table *name*** Specify the name of the table to print. Currently supported tables:
- esrt** EFI System Resource Table
  - prop** EFI Properties Table
- u *uuid* --uuid *uuid*** Specify the UUID of the table to print.

**HISTORY**

The **efitable** utility first appeared in FreeBSD 14.0.