

**NAME**

**mwlfw** - Firmware Module for Marvell 88W8363 Wireless driver

**SYNOPSIS**

To compile this module into the kernel, place the following line in your kernel configuration file:

```
device mwlfw
```

Alternatively, to load the driver as a module at boot time, place the following line in loader.conf(5):

```
mwlfw_load="YES"
```

**DESCRIPTION**

This module provides access to firmware sets for the Marvell 88W8363 IEEE 802.11n wireless adapters. It may be statically linked into the kernel, or loaded as a module.

**SEE ALSO**

mw(4), firmware(9)