

NAME

snd_cmi - CMedia CMI8338/CMI8738 PCI bridge device driver

SYNOPSIS

To compile this driver into the kernel, place the following lines in your kernel configuration file:

```
device sound
device snd_cmi
```

Alternatively, to load the driver as a module at boot time, place the following line in loader.conf(5):

```
snd_cmi_load="YES"
```

DESCRIPTION

The **snd_cmi** bridge driver allows the generic audio driver sound(4) to attach to the CMedia CMI8338/CMI8738 audio cards.

HARDWARE

The **snd_cmi** driver supports the following sound cards:

- ⌚ CMedia CMI8338A
- ⌚ CMedia CMI8338B
- ⌚ CMedia CMI8738
- ⌚ CMedia CMI8738B

SEE ALSO

sound(4)

HISTORY

The **snd_cmi** device driver first appeared in FreeBSD 4.3.

AUTHORS

Orion Hodson <*O.Hodson@cs.ucl.ac.uk*>