#### **NAME**

acpi\_asus - Asus Laptop Extras

#### **SYNOPSIS**

To compile this driver into the kernel, place the following line in your kernel configuration file:

## device acpi\_asus

Alternatively, to load the driver as a module at boot time, place the following line in loader.conf(5):

```
acpi_asus_load="YES"
```

#### DESCRIPTION

The **acpi\_asus** driver provides support for the extra ACPI-controlled gadgets, such as hotkeys and leds, found on recent Asus (and Medion) laptops. It allows one to use the sysctl(8) interface to manipulate the brightness of the LCD panel and the display output state. Hotkey events are passed to devd(8) for easy handling in userspace with the default configuration in /etc/devd/asus.conf.

Currently, the following Asus laptops are fully supported:

xxN

A1x

A2x

A<sub>3</sub>N

A4D

A6VM

D1x

J1x

L2B

L2D

L2E

L3C

L3D

L3H

L4E

L4R

L5x

L8x

M1A

M<sub>2</sub>E

M<sub>6</sub>N

M6R

S1x

S2x

V6V

W5A

Eee PC

Additionally, **acpi\_asus** also supports the Asus-compatible *ATK0100* interface found in *Samsung P30/P35* laptops.

#### SYSCTL VARIABLES

The following sysctls are currently implemented:

hw.acpi.asus.lcd\_brightness

Makes the LCD backlight brighter or dimmer (higher values are brighter).

hw.acpi.asus.lcd\_backlight

Turns the LCD backlight on or off.

hw.acpi.asus.video\_output

Sets the active display to use according to a bitwise OR of the following:

- 0 No display
- 1 LCD
- 2 CRT
- 4 TV-Out

Some models also support video switching via the generic acpi\_video(4) driver. Most models do not, however.

Defaults for these variables can be set in sysctl.conf(5), which is parsed at boot-time.

### **SEE ALSO**

```
acpi(4), acpi_asus_wmi(4), acpi_video(4), sysctl.conf(5), sysctl(8)
```

The acpi4asus Project, http://sourceforge.net/projects/acpi4asus/.

# **HISTORY**

The acpi\_asus driver first appeared in FreeBSD 5.3.

## **AUTHORS**

The acpi\_asus driver and this manual page were written by Philip Paeps epsD.org>.

Inspiration came from the *acpi4asus project* started by Julien Lerouge which maintains a driver implementing this functionality in the Linux kernel.