

NAME

acpi_toshiba - Toshiba HCI interface

SYNOPSIS

To compile this driver into the kernel, place the following line in your kernel configuration file:

```
device acpi_toshiba
```

Alternatively, to load the driver as a module at boot time, place the following line in loader.conf(5):

```
acpi_toshiba_load="YES"
```

DESCRIPTION

HCI is Toshiba's *Hardware Control Interface* which is somewhat uniform across their models. The **acpi_toshiba** driver allows the user to manipulate HCI-controlled hardware using a number of sysctl(8) variables.

SYSCTL VARIABLES

The following sysctls are currently implemented:

hw.acpi.toshiba.force_fan

Causes active cooling to be forcibly enabled ('1') or disabled ('0') regardless of the current temperature.

hw.acpi.toshiba.video_output

Sets the active display to use according to a bitwise OR of the following:

- | | |
|---|------------|
| 0 | No display |
| 1 | LCD |
| 2 | CRT |
| 4 | TV-Out |

Only some systems (i.e., the Libretto L5) support video switching via this hardware-specific driver. Use the acpi_video(4) driver for generic video output support.

hw.acpi.toshiba.lcd_brightness

Makes the LCD backlight brighter or dimmer (higher values are brighter).

hw.acpi.toshiba.lcd_backlight

Turns the LCD backlight on and off.

hw.acpi.toshiba.cpu_speed

Sets the CPU speed to the specified speed. This provides functionality similar to the *hw.acpi.cpu.throttle_state* variable. Higher sysctl values mean lower CPU speeds.

Defaults for these variables can be set in *sysctl.conf(5)*, which is parsed at boot-time.

LOADER TUNABLES

The *hw.acpi.toshiba.enable_fn_keys* tunable enables or disables the function keys on the keyboard. Function keys are enabled by default.

This behaviour can be changed at the *loader(8)* prompt or in *loader.conf(5)*.

SEE ALSO

acpi(4), *acpi_video(4)*, *loader.conf(5)*, *sysctl.conf(5)*, *sysctl(8)*

HISTORY

The **acpi_toshiba** driver first appeared in FreeBSD 5.1.

AUTHORS

The **acpi_toshiba** driver was written by Hiroyuki Aizu <*aizu@navi.org*>. This manual page was written by Philip Paeps <*philip@FreeBSD.org*>.