

NAME

cue - CATC USB-EL1210A USB Ethernet driver

SYNOPSIS

To compile this driver into the kernel, place the following lines in your kernel configuration file:

```
device uhci
device ohci
device usb
device miibus
device uether
device cue
```

Alternatively, to load the driver as a module at boot time, place the following line in loader.conf(5):

```
if_cue_load="YES"
```

DESCRIPTION

The **cue** driver provides support for USB Ethernet adapters based on the Computer Access Technology Corporation's USB-EL1210A chipset.

The USB-EL1210A supports a 512-bit multicast hash filter, single perfect filter entry for the station address and promiscuous mode. Packets are received and transmitted over separate USB bulk transfer endpoints.

The CATC chipset supports only 10Mbps half-duplex mode, hence there are no **ifmedia()** modes to select.

For more information on configuring this device, see ifconfig(8).

HARDWARE

The **cue** driver supports CATC USB-EL1210A based USB Ethernet adapters including:

- ⬢ Belkin F5U011/F5U111
- ⬢ CATC Netmate
- ⬢ CATC Netmate II
- ⬢ SmartBridges SmartLink

DIAGNOSTICS

cue%d: watchdog timeout A packet was queued for transmission and a transmit command was issued,

however the device failed to acknowledge the transmission before a timeout expired.

cue%d: no memory for rx list The driver failed to allocate an mbuf for the receiver ring.

SEE ALSO

arp(4), netintro(4), ng_ether(4), ifconfig(8)

HISTORY

The **cue** device driver first appeared in FreeBSD 4.0.

AUTHORS

The **cue** driver was written by Bill Paul <wpaul@ee.columbia.edu>.